

Bulletin #	010-94398
Models Affected	No519
Versions	All Versions
Topic	No519 RS232 Control Codes

P1 Pin Assignment

- 1 - Not Used
- 2 - Red Wire
- 3 - Black Wire
- 4 - Not Used
- 5 - Yellow Wire
- 6 - Not Used
- 7 - Not Used
- 8 - Not Used
- 9 - Not Used

P2 Pin/Wire Assignment

- 1 – Blue (Cut and tuck into connector)
- 2 – Yellow (Pin 5 of P1)
- 3 – Green (Cut and tuck into connector)
- 4 – Red (Pin 2 of P1)
- 5 – Black (Pin 3 of P1)
- 6 - White (Cut and tuck into connector)

Material:
9 Position D-Sub – F to 6 Pin Modular Jack – F (DigiKey P/N AE10308-ND)

Settings
115200 Baud
8 Bits
No Parity
1 Stop Bit

RS232 Control Codes					
INTENSITY	!1003	IN_STANDBY	!1039	OPTICAL 2	!1049
STANDBY	!1005	BLUETOOTH	!103A	USB AUDIO	!104A
ENTER	!100F	SPOTIFY	!103B	PLAYLISTS	!104B
SETUP	!1015	TIDAL	!103C	NETWORK	!104C
BACK	!1016	QOBUZ	!103D	IN_MUTE	!1050
UP	!1017	DEEZER	!103E	OUT_MUTE	!1051
DOWN	!1018	RADIOS	!1041	STOP	!1052
CLARI-FI	!1019	PODCASTS	!1042	PLAY	!1053
VOL_DOWN	!1030	DISC	!1043	NEXT TRACK	!1054
VOL_UP	!1031	USB DRIVE	!1044	PREVIOUS TRACK	!1055
MUTE	!1032	BALANCED	!1045	Set Clari-Fi Off	!C000
PREV_IN	!1035	COAXIAL 1	!1046	Set Clari-Fi On	!C001
NEXT_IN	!1036	COAXIAL 2	!1047	Variable Output	!O000
OUT_STANDBY	!1038	OPTICAL 1	!1048	Fixed Output	!O001

All Control Codes need to be terminated with a Carriage Return <CR>

When something is entered correctly, the return prompt will be OK:

When something is entered incorrectly, the return prompt will be Invalid Command